

INSTALLATION INSTRUCTIONS FOR ABB'S AVIC MODIFICATIONS (draft as of 2010-10-26)	
MY FLASH DISK	STORAGE CARD
CHROME NAV MOD V4.0 INSTRUCTIONS	
1)INSERT Freshly formatted 4Gb (to allow space for backup) SD Card with TESTMODE & files extracted from RAR NAV MOD v4.0, NEW GFX, & NEW SCHEMES & Start Car	
2)Click START/PROGRAMS/WINDOWS EXPLORER; DOUBLE CLICK 'My Flash Disk' Icon (results in My Flash Disk item in Quick Start at bottom of window for easier toggling in subsequent steps)	3)Click START/PROGRAMS/ WINDOWS EXPLORER; DOUBLE CLICK 'Storage Card' Icon (results in Storage Card item in addition to My Flash Disk folder in Quick Start at bottom of window for easier toggling in subsequent steps)
4)Click My Flash Disk folder on Quick Start at bottom of window. Double Click 'My Flash Disk' Icon; Click EDIT/SELECT ALL/COPY (about 10 minutes to complete)	5) Click Storage Card button on Quick Start at bottom of window. Click FILE/PASTE (about 35 minutes to complete). When complete 8 files (TESTMODE, My Flash Disk (backup copy), 3 (Put All CONTESTS ...) files, GFX, Schemes, and Instructions. Backup is completed.
	6) DOUBLE CLICK Folder 'put ALL CONTENTS IN My Flash Disk' ; Click EDIT/SELECT ALL/COPY
7) CLICK My Flash Disk folder on Quick Start at bottom of window. DOUBLECLICK My Flash Disk icon; DOUBLECLICK My Flash Disk\SYSTEM folder; then Click EDIT/PASTE. Install Step #1 is completed.	8) CLICK Storage Card button on Quick Start at bottom of window; DOUBLECLICK folder 'put ALL CONTENTS IN My Flash Disk\APL'; Click EDIT/SELECT ALL/COPY
9) CLICK My Flash Disk button on Quick Start at bottom of window. DOUBLECLICK FLASHDISK icon; DOUBLECLICK My Flash Disk\APL folder, then Click EDIT/PASTE. Install Step #2 is completed.	10) CLICK Storage Card button on Quick Start at bottom of window; DOUBLECLICK folder 'put ALL CONTENTS IN My Flash Disk\APL2\GO'; Click EDIT/SELECT ALL/COPY
11) CLICK My Flash Disk button on Quick Start at bottom of window. DOUBLECLICK FLASHDISK icon; DOUBLECLICK My Flash Disk\APL2\GO folder, then Click EDIT/PASTE. Select 'Yes to all' if prompted, 3 minute process. Install Step #3 is completed.	
12)NAVIGATE to up to My Flash Disk\USER\USER DATA\IGO; DOUBLE CLICK IGO, then Click EDIT/SELECT ALL/ CUT (or simply use 'X' at top of screen when IGO selected). Install Step #4 is completed.	
13)Power off car ignition to turn off AVIC unit 14)Remove SD Card 15) Power on car ignition (without SD Card) to check out new functionality. Should have everything but Sky Schemes.	
NEW SCHEMES INSTALLATION INSTRUCTIONS (after file transfers for MOD V4.0)	
INSERT same SD Card TESTMODE & files extracted from NAV MOD v4.0, NEW GFX, & NEW SCHEMES, plus the Backup copy of MY FLASH DISK & Start Car (Repeat items #2 & #3 if this helps).	
1)CLICK My Flash Disk \APL2\GO\CONTENT\MAP & POI &/or BUILDINGS (individually deleting Alaska, Hawaii, PR, or other unneeded files in each folder, up to 5 files in this example for needed additional space; USA users may want to delete Canada & related POI & BUILDINGS files using the 'X' icon on top menu bar)	
2) Navigate backup to My Flash Disk (using '↑' and/or '←' icons on top menu bar then down to \APL2\GO\GFX (delete contents of folder using EDIT/SELECT ALL/CUT contents of GFX)	3) CLICK Storage Card button on Quick Start at bottom of window. DOUBLE CLICK <u>GFX</u> , Click EDIT/SELECT ALL/COPY
4))CLICK My Flash Disk\APL2\GO\GFX. DOUBLE CLICK GFX, Click EDIT/PASTE	5) CLICK Storage Card button on Quick Start at bottom of window. DOUBLE CLICK <u>Schemes</u> ; Click EDIT/SELECT ALL/ COPY
6) CLICK My Flash Disk\APL2\GO\CONTENT SCHEMES. DOUBLE CLICK SCHEMES, Click EDIT/PASTE	
7)Power off car ignition to turn off AVIC unit 8)Remove SD Card 9) Power on car ignition (without SD Card) to check out new functionality. Should now have Sky Schemes 10)Read up on accessing new functionality & enjoy!	

