


Connector Terminal Views

335. Multiplex Control Unit, Driver's

– Under left side of dash

Connector A

– Connects driver's multiplex control unit to driver's under-dash fuse/relay box



- 1 (Multiplex control system)
- 2 (Multiplex control system)
- 3 (A/T park position circuit)
- 4 (A/T park/neutral position circuit)
- 5 EX-L: (Security system)
- 6 (Illumination (positive) circuit)
- 7 (Power windows)
- 8 (Brake pedal position circuit)
- 9 (Front wiper/washer)
- 10 USA: (Headlights)
Canada: (Headlights)
- 11 (Front wiper/washer)
- 12 (Fuse 13 – Passenger's)
- 13 (Key-in ignition circuit)
- 14 (G401)
- 15 (Multiplex control system)
- 16 (Driver's door position circuit)
- 17 (Left rear door position circuit)
- 18 —
- 19 (Power windows)
- 20 —
- 21 (Front wiper/washer)
- 22 (Taillight relay control circuit)
- 23 (Front wiper/washer)
- 24 (Fuse 9 – Driver's)

Connector B

– GRN
– On dashboard wire harness A (left branch)



- 1 PNK (Multiplex control system)
- 2 EX, EX-L: GRN/BLK (Security system)
- 3 —
- 4 —
- 5 —
- 6 EX, EX-L: YEL (Security system)
- 7 —
- 8 ORN (Tailgate position circuit)
- 9 GRN/YEL (Front wiper/washer)
- 10 GRN/WHT (Front wiper/washer)
- 11 BLK (G501)
- 12 —
- 13 EX, EX-L: RED/WHT (Headlights)
- 14 BLU/WHT (Vehicle speed sensor circuit)
- 15 GRN/RED (Parking brake position circuit)
- 16 EX, EX-L: RED/GRN (Lights-on indicator)
- 17 —
- 18 —
- 19 —
- 20 —
- 21 —
- 22 —

