



**MODULE-
POWERTRAIN
CONTROL C2
(SRT)**

MODULE-POWERTRAIN CONTROL C2 (SRT) - BLACK/GRAY 32 WAY

CAV	CIRCUIT	FUNCTION
1	T54 18DG/OR (A/T)	TRANSMISSION TEMPERATURE SENSOR SIGNAL
2	K26 18BR/YL	INJECTOR CONTROL NO. 7
3	K115 18BR	INJECTOR CONTROL NO. 9
4	K11 18BR/YL	INJECTOR CONTROL NO. 1
5	K13 18BR/LB	INJECTOR CONTROL NO. 3
6	K38 18BR/OR	INJECTOR CONTROL NO. 5
7	-	-
8	T118 18DG (A/T)	GOVERNOR PRESSURE SOLENOID CONTROL
9	-	-
10	K20 18BR/GY	GEN FIELD CONTROL
11	T75 18YL/LB (A/T)	TORQUE CONVERTER CLUTCH SOLENOID CONTROL
12	K58 18BR/VT	INJECTOR CONTROL NO. 6
13	K28 18BR/LB	INJECTOR CONTROL NO. 8
14	K116 18BR/LG	INJECTOR CONTROL NO. 10
15	K12 18BR/DB	INJECTOR CONTROL NO. 2
16	K14 18BR/TN	INJECTOR CONTROL NO. 4
17	C240 18LB/TN	HYDRAULIC COOLING CONTROL FEED
18	-	-
19	C918 18BK/LB	A/C PRESSURE GROUND
20	-	-
21	T9 18DG/TN (A/T)	3-4 SOLENOID CONTROL
21	K333 18DB/LB (M/T)	SOLENOID REVERSE LOCKOUT FEED
22	-	-
23	G6 18VT/GY	OIL PRESSURE SIGNAL
24	-	-
25	T13 18DG/VT (A/T)	SPEED SENSOR GROUND
26	-	-
27	K75 18DB/OR	VEHICLE SPEED SIGNAL NO. 1
28	T14 18DG/BR (A/T)	OUTPUT SPEED SENSOR SIGNAL
29	T38 18YL/BR (A/T)	GOVERNOR PRESSURE SENSOR SIGNAL
30	T515 18YL/DB (A/T)	TRANSMISSION CONTROL
31	F856 18YL/PK	5 VOLT SUPPLY
32	-	-