



ATX
*: VACANT




777


0140-01
PCM(E)



0140-20
MASS AIR FLOW/INTAKE AIR TEMPERATURE SENSOR(E)




0140-21
INPUT/TURBINE SPEED SENSOR(E)



(ATX)

0140-21
VEHICLE SPEED SENSOR(E)



(ATX)

HARNESS SYMBOL :  (F)  (E)  (R)

55

